



## **MORE TO LIFE TANK OPERATING INSTRUCTIONS**

### **LOADING THE MORE TO LIFE TANK**

- **To remove the basket, use heat resistant gloves.** Temperature is over 80 degrees Celsius. Rubber washing up gloves should also be used for sensitive skin. The cleaning solution is not toxic or corrosive and will not harm skin or clothes. **HOWEVER, DO NOT PUT BARE HANDS INTO THE WATER AS IT IS HOT.**
- Lift the basket to a comfortable working height and lock into position
- Load the basket, ensuring that trays, tins, wires are laying on their side
- Follow directions for cleaning times. If items are still very dirty, resoak overnight, thoroughly rinse with cold water and repeat as necessary.
- **PLEASE NOTE THAT TEFLON COATED PANS OR TRAYS, ANYTHING PLASTIC, SILVER, COPPER OR MADE OF WOOD - SHOULD NOT BE SOAKED IN THE TANK AS THEY WILL BE DAMAGED.**

### **UNLOADING THE MORE TO LIFE TANK**

- Open the lid
- To remove the basket, use heat resistant gloves
- Lift the basket to a comfortable working height and lock into position
- Remove clean items and thoroughly rinse with cold water. Gloves should be worn (as for normal washing operations)
- Reload the tank
- Lower the basket into the water to the desired level
- Close the lid

### **MAINTENANCE**

- Ensure the tank is turned on (indicator light on side will glow). Ensure that water inside of tank is hot and steam is visible when lid is opened
- Check the water level and top up to the level indicator mark as required. Water will evaporate in the form of steam and removal of items that are clean
- Skim any excess fats or oils on the surface of the water and dispose of in a waste bin – this should be done daily or as required.
- Exterior of tank should be wiped over lightly with a damp cloth daily

### **EMERGENCY PROCEDURE**

- Turn off the More To Life tank at the switch on the side of the unit
- Unplug the tank from the plug wall socket
- Call your More To Life Representative
- Consult the MSDS sheet if required – see your store manager